



**CLAYS BASKET  
WILL FIT E-Z-GO® RXV®  
INSTALLATION INSTRUCTIONS  
04-012**

**INCLUDED:  
MADJAX CLAYS BASKET  
BRACKETS  
HARDWARE PACK**



**1**  
\*Remove front strut bolt cover.  
Remove and retain top strut bolt.



**2**  
Attach bracket using retained hardware. \*Bracket ear should be on the outside of the cart. Tighten as shown.



Attach Clays Basket using supplied hardware and tighten as shown.

VISIT [WWW.MYMADMJAX.COM](http://WWW.MYMADMJAX.COM) FOR MORE  
INSTALLATION VIDEOS AND PRODUCTS

## CLAYS BASKET HARDWARE PACKS

### HARDWARE PACK 1

- (4) 10MM X 20MM BOLTS
- (8) 10MM WASHERS
- (4) 10MM ANTI-SLIP NUTS
- (2) BRACKETS
- (1) CLAYS BASKET

