



Part # 04-062
Clays Basket
Fits E-Z-GO Liberty



ITEMS INCLUDED

- Left & Right Brackets
- Hardware Pack:
 - 4 - 8mm x 40mm Hex Head Bolts
 - 8 - 8mm Flat Washers
 - 4 - 8mm Nylock Nuts

TOOLS NEEDED

- Ratchet
- T40 TORX
- 13mm Socket
- 13mm Wrench



Left & Right Brackets (04-061)



Clays Basket (04-020)
Sold Separately

NOTICE: Any modifications to these products will void the warranty. Any damages that occur to the vehicle as of modifying this product is the sole responsibility of the installer.

STEP 1



T40 TORX

Begin on one side by removing the top bolt only then back the lower bolt out about half way.

NOTE: Install one side at a time



STEP 2



T40 TORX

Slide slotted end over the lower bolt. Line up the top bolt with the brush guard and retighten. Repeat on the other side.

NOTE: See Bracket Orientation below



*Bracket Orientation
(Top View)*



*Bracket Orientation
(Side View)*

ATTENTION: Ensure that the flat edge of the mounting bracket is facing the inside of the cart as shown.

STEP 3



13MM SOCKET & WRENCH

Attach clays basket to brackets on both sides using hardware pack provided.



INSTALLATION COMPLETE