



Storm Fender Flare Extensions

STEP 1

Drill out rivets on existing front fender flares, and remove fender flares from the vehicle.

STEP 2

Using heat gun and pliers, heat up the mounting tabs until pliable (approximately 8 seconds) as shown, and bend the tabs down to contour to the storm fender flare mounting locations.

NOTE:

Be sure not to heat them up too much as it will cause the material to deform.



STEP 3

Using a 1/4" drill bit, drill out the holes in your fenders and fender flares so that the 1/4-20 bolts can pass through the hole. Feed the 1/4-20 bolts with washers through the holes in your fender flares as shown.



STEP 4

Secure the fender flare extensions to the fender flares to mark and drill out the hole for the push rivet into the storm fender flare.



STEP 5

Using a 21/64" or equivalent size drill bit, drill out the hole for the push rivet into the Storm fender flares.



STEP 6

Secure the fender flares and fender flare extensions to the cart using the washers and 1/4-20 nyloc nuts.



INSTALLATION COMPLETE
